


LED Downlight 9W Module RGBW


Connection diagram



Note #1: Ensure that the number of downlights does not surpass the maximum limit specified in the voltage table

Note #2: Follow the above instructions to connect the splitter using the RJ45Couple marking to indicate the inputs and outputs. Ensure that the loop is closed by connecting the OUT to a downlight ,otherwise it will result in a non-functional system.

UTP Connector Internal Wiring



Disclaimer

Due to the technical evolution and improvement of our products, the data provided in this document may be updated on a regular basis, and as such, confirmation of this information is strongly recommended prior to the order process. OneEightyOne is not responsible for any discrepancies in this document following changes in our products. We reserve the right to make technical changes to our products and to change information, at its sole discretion, without notice.