LTECH

DMX512 DECODER

IT-995-01 FD








www.ltech-led.com



Product Introduction:

- 1. Designed with 5 channels output, and Max. 6A current per channel, up to 720W output power.
- 2. Easy operation with OLED screen and the touch buttons.
- 3. 5 kinds of mode optional: single color, CT, RGB, RGBW, RGBWY.
- 4. Support 3 kinds of DMX ports with signal isolation function: 3-pin XLR, RJ45, green terminal.
- 5. With RDM remote management protocol, the operations can be completed via the RDM master console, such as parameters browsing & setting, DMX address setting, equipment recognition, etc.
- 6. With shortcut protection and over load protection, as well as warning function when fault.
- 7. With fast self-testing function.
- 8. 16bit (65536 levels) / 8bit (256 levels) grey level optional.
- 9. Multiple dimming curve (0.1~9.9) optional.

















Protection



Technical Specs:

Model · 1T-995-01 FD

Input Signal: DMX512/RDM

Input Voltage: 12~24Vdc

6A × 5CH Max. 30A Current Load :

[0~72W...144W] × 5CH Max. 720W Output Power: DMX Interface: 3-pin XLR, RJ45, green terminal

Control Mode : Dimming/CT/RGB/RGBW/RGBWY

Dimming Curve: 0.1~9.9

8bit [256 levels] / 16bit [65536 levels] Grey Level:

Protection: Shortcut / Over load

Working Temperature : -30°C~65°C

Dimensions: I 169×W80×H39mm L182×W91×H41mm Package Size :

Weight (G.W.): 550g








ITECH

Product Size:

Unit: mm



Main Component Descripition:







OLFD Screen Interface:



Press "M" key, switch entries. Long press "M" key, back to main page. Press "^" or "v" key, parameter adjustment. Exit: back to previous page.

4. Grey Level

DMX: 001 Hz: High Mode: RGB Curve: Standard Dim: Smo TOOL&v

Press "^" or "v" key to choose.

Optional: 8bit

16hit (choose it if the master controller support this function

1 DMX Address Setting

DMX: 001 Hz: High Mode: RGB Curve: Standard Dim: Smo TOOL&v

Press "^" or "v" key to set DMX address.

Main page

Range: 001~512

Press "^" or "v" key to choose.

DMX: 001 Hz: High Mode: RGB Curve: Standard Dim: Smo TOOL&v

No flicker in Optional: video camera. Std (standard) Hiah Mid (middle) Low Smooth and delicate, * It is recommended to human eye is comfortable. use standard.

3 Mode

2. PWM

Frequency

DMX: 001 Hz: High Mode: RGB 8bit Curve: Standard Dim: Smo TOOL&v

Press "^" or "v" key to choose.

Optional : Dim CT RGB

RGBW

RGRWY

5. Dimmina Curve



Press "^" or "v" key to choose.

Optional: Standard Linear 0.1~9.9


It is recommended to use standard, 0.1-9.9 is for special requirements.

6. Enhance Dimmina DMX: 001 Hz: High Mode: RGB Curve: Standard Dim: Smo TOOL&v Press "^" or "v" key to choose.

Optional : Std (standard) Smo (smooth) * It is recommended to use standard.

Smo: This option with smooth processing. realize the dimming flicker-free and dynamic effects more downy.





Screensaver open and

DMX: 001 Hz: High Mode: RGBW 8bit Curve: Standard Dim: Smo TOOL&v

Screen: 0FF Screensaver is not open. * Fast self-testing function: press "^"or "v" keys simultaneously for 2-3 seconds under any page, decoder will enter self-testing function.




LTECH

LTECH


Wiring Diagram:


1 DMX console connection:




* If the recoil effect occurs because of longer signal line or bad line quality, please try to connect 0.25W 90-120 Ω terminal resistor at the end of each line.

2 Connecting LED lights:






LTECH




3. The connection diagram of 3 kinds of DMX/RDM terminals:



These 3 terminals can be connected in a mixed way.

4. The connection diagram of AMP signal amplifier terminal:

* Connecting with green terminal or an extra amplifier will be needed when more than 32 decoders are connected or use overlong signal wire(as shown below). Signal amplifier should not be more than 5 times continuously.





Address setting table

Mode		DIM	СТ	RGB	RGBW	RGBWY
Address Quantity		1	2	3	4	5
Resolution		8bit	8bit	8bit	8bit	8bit
Channel	1	001	001	001	001	001
	2	001	002	002	002	002
	3	001	001	003	003	003
	4	001	002	003	004	004
	5	001	002	003	004	005

Mode		DIM	CT	RGB	RGBW	RGBWY
Address Quantity		2	4	6	8	10
Resolution		16bit	16bit	16bit	16bit	16bit
Channel	1	001 002	001 002	001 002	001 002	001 002
	2	001 002	003 004	003 004	003 004	003 004
	3	001 002	001 002	005 006	005 006	005 006
	4	001 002	003 004	005 006	007 008	007 008
	5	001 002	003 004	005 006	007 008	009 010



Attention.

- 1. The product shall be installed and serviced by the qualified person.
- This product is non-waterproof. Please avoid the sun and rain. When installed outdoors please ensure it is mounted in a water proof enclosure.
- Good heat dissipation will prolong the working life of the controller. Please ensure good ventilation.
- Please check if the output voltage of the LED power supply used comply with the working voltage of the product.
- Please ensure that adequate sized cable is used from the controller to the LED lights to carry the current. Please also ensure that the cable is secured tightly in the connector.
- Ensure all wire connections and polarities are correct before applying power to avoid any damages to the LED lights.
- If a fault occurs, please return the product to your supplier. Do not attempt to fix this product by yourself.

Warranty Agreement:

- 1. We provide lifelong technical assistance with this product:
 - A 5-year warranty is given from the date of purchase. The warranty is for free repair or replacement if cover manufacturing faults only.
 - For faults beyond the 5-year warranty, we reserve the right to charge for time and parts.
- 2. Warranty exclusions below:
 - Any man-made damages caused from improper operation, or connecting to excess voltage and overloading.
 - The product appears to have excessive physical damage.
 - Damage due to natural disasters and force majeure.
 - Warranty label, fragile label and unique barcode label have been damaged.
 - The product has been replaced by a brand new product.
- Repair or replacement as provided under this warranty is the exclusive remedy to the customer. We shall not be liable for any incidental or consequential damages for breach of any stipulation in this warranty.
- Any amendment or adjustment to this warranty must be approved in writing by our company only.
- igstar This manual only applies to this model. We reserve the right to make changes without prior notice.